




Assembly Instructions

WÜNDER®




THE DISC

Simple, robust and stunning. The Disc has a special 'je ne sais quoi' that draws all attention to it. The lamp was originally designed especially for The Table. But it lights up any other table just as nicely. Available in yellow and grey.

SUPPLIES

- Wrench 9 mm



Arm 2x

Turnbuckle

D - Closure

Steel Cable

Bracket 2x

CONTACT



Questions, comments or suggestions regarding our products or our website? Feel free to get in touch with us!

Wünder - Ovenhoek 5, 8800 Roeselare, België
+32 51 79 17 31 - info@wunder.be



01


- Mount the bracket on the arm as shown




*ON YOUR OWN TABLE

02

- Screw the bracket to the middle shelf of The Table's top.




- Screw the bracket to the edge of the table top.



*ON YOUR OWN TABLE


03

- Use the D-clasp to attach the fixed end of the wire rope to the arm.




04


- Screw the turnbuckle fully open before attaching the other end of the wire rope.

**05**

- Tighten the turnbuckle until the wire rope hangs nice and tight.

**06**

- Wind the cable of the fixture around the steel cable. Start along the side of the armature.



07

- Screw the lamp into the fixture.
- Connect The Disc to a grounded socket.

